

Installation of 2 x Proxima ISDN Lite: 2 x B-channels bundled 128 K ?

AT-commands viaHyperterminal:

Answering :

```
-----  
at&o13s0=1      ML-V.120 and answer 1 ring  
at#nb2b        MSN-number in ML-V.120 slot  
at#z           Save # instructions  
at&w           Save ordinary AT commands
```

Originating :

```
-----  
at&o13          ML-V.120  
at&w           Save ordinary AT commands
```

At both sides using 'Proxima ISDN Lite ML-V.120 modem