

## sa BAUSCH DATACOM nv Addendum for MAC users

On this 'MAC Driver' CD-ROM you will find the following MAC modem scripts

- Proxima External Modems

This script file is for ALL external Bausch modems eg. Proxima V.34 Full / Proxima V.34 Lite / Proxima V.34 Lite Voice / Proxima 56 Lite Voice / Proxima Dual (only for serial connection).

- Proxima STAR II

This script file is for the Proxima STAR II PCMCIA card modem. You can choose between a modem, PPP, V.120 or X.75 script according to the connection (B-channel protocol) you want to establish.

- Proxima STAR ISDN

This script file is for the Proxima STAR ISDN PCMCIA card modem. You can choose between a PPP, V.120 or X.75 script according to the connection (B-channel protocol) you want to establish.

- Proxima ISDN Lite

This script file is for the Proxima ISDN Lite terminal adaptor. You can choose between a PPP, V.120, MLPPP or MLV.120 script according to the connection (B-channel protocol) you want to establish.

- Proxima USB

This installation file (PROXUSB.HQX) is for the Proxima USB modem. After executing this file the Proxima USB will automatically be installed as 'USB 56K modem card'.

Notes :

- You will find each script file in a compressed .sit file AND in a separate folder.
- If you want to establish an Internet connection over ISDN you have to select a PPP script.
- To use a modem script file, place the file in the modem script folder (located in the Extension Folder) or drop it on your closed system folder icon.
- After installing the Bausch modem script you have to select the modem in 'Modems' in the 'Control Panel'.

### **HOTFAX FAXstf Lite**

Fax send and receive software for MAC

- Proxima External Modems / Proxima STAR II

During or after the installing of the FAXstf software you have to choose a modem. Please select 'Selected by Driver Type' and choose 'CLASS 1 for Rockwell Based 14400 send/receive modems'.

- Proxima USB

During or after the installing of the FAXstf software you have to choose a modem. Please select 'Selected by Driver Type' and choose 'USB Lucent Modem'.

- Proxima Star ISDN / Proxima ISDN Lite

No analogue fax support is possible.